

FrontRow Juno – Quick Guide


Juno: All-in-one Classroom Audio

This guide has been designed to support the use of your Juno systems. It will provide you a quick overview of components and how to use them.



Activate Juno Speaker and Microphones:


1. Turn Tower on.
2. Place microphone around neck and connect clasp.
3. Adjust neck straps to position microphone approximately 5in (14cm) from mouth.



Sleep Mode

For daily use, you do not need to turn the Speaker on and off. The Speaker will wake up from its energy-saving standby mode whenever you turn on a microphone or play audio through one of the audio connections. The Speaker will go back to sleep 30 minutes after your microphones enter sleep mode or you stop playing audio. After 2 hours and 30 minutes, the Speaker will enter an energy-saving deep sleep mode. When waking up the Speaker from this state, it will take approximately 30seconds.

Control Panel:



We recommend that the volume of the speaker be set to between 15 - 17.

Pendant Microphones



Mute Indicator:
OFF/STANDBY: Unmuted
SOLID RED: Muted

Power Indicator:
SOLID GREEN: Power On
OFF: Standby

One-Touch Button:
When the Pendant Microphone is active:
PRESS MOMENTARILY: Mute / Un-mute
PRESS AND HOLD: Issue Voice Command

Pass-Around Microphones

Battery Indicator:
In Use
OFF: Battery Charged
FLASHING RED: Battery Low
When Charging
SOLID RED: Charging
SOLID GREEN: Fully Charged
FLASHING RED/GREEN: Charge fault



Power Indicator:
SOLID GREEN: Power On
OFF: Power Off

Power/Push-to-talk Switch:
PRESS AND HOLD: Push-to-talk
PRESS AND SLIDE UP: Power On